







SANITARY PRESSURE REDUCING VALVE In-line design P173

DESCRIPTION

The ADCA P173 series direct acting, spring-loaded diaphragm sensing, pressure reducing valves are designed for use with clean steam, compressed air, water and other gases or liquids compatible with the construction materials.

MAIN FEATURES

Compact in-line design.

Completely machined from bar stock material, no castings or forgings are used on the standard version.

No rising stem.

STANDARD SURFACE FINISH

Internal wetted parts: ≤ 0,51 micron Ra – SF1.

External: ≤ 0,76 micron Ra – SF3.

Other surface conditions see IS PV20.00 E – Technical information.

Ultrasonic cleaning.

OPTIONS: Leakage line connection 1/8" (captured vent).

Different soft valves for liquids and gases.

Lock system, allows clean-in-place (CIP) and sterilization-in-place (SIP) operations with valve

in line.

Gauge connection on body.

With or without bottom drain connection.

USE: Clean steam, compressed air, water and

other gases and liquids compatible with the

construction.

AVAILABLE

MODELS: P173.

SIZES: 11/2", 2"; DN 32 to DN 50.

OUTLET SPRING

RANGES: 0.8 - 1.5 bar; 1 - 3 bar; 1.5 - 5 bar.

CONNECTIONS: Clamp ferrules or others on request.

PACKAGING: Assembling and packaging in a clean room

certified according to ISO 14644-1.

The product is end capped and sealed with recyclable thermo-shrinkable plastic film, to

avoid contamination.

INSTALLATION: Horizontal installation. See IMI – Installation and

maintenance instructions.

ORDER

REQUIREMENTS: Type of fluid.

Maximum operating temperature.

Inlet and outlet pressures.

Flow rate (maximum and minimum).





LIMITING CONDITIONS	
Valve model	P173
Body design conditions	PN16
Max. upstream pressure	8 bar or 4 bar *
Max. downstream pressure	5 bar
Min. downstream pressure **	0,8 bar
Max. design temperature ***	150 °C

^{*} See "Capacities" table.

^{***} Others on request.

CE MARKING – GROUP 2 (PED – European Directive)						
PN16	Category					
11/2"; 2"; DN 32 to DN 50	SEP					



^{**} For tight shut off, with the regulating spring relaxed, ensure a minimum 0,2 bar downstream pressure.





				CAPAC	ITIES							
		BPE			DIN		ISO					
Valve size	11/2"	2"	2" *	40	50	50 *	32	40	50			
Kvs	5,5	5,5	8,5 *	5,5	5,5	8,5 *	5,5	5,5	NA			

^{*} Limited to a maximum of 4 bar inlet pressure.


				DI	MENSI	ONS (I	mm) AS	SME B	PE					
SIZE	Α	В	B1	С	D	d1	d2	Е	F	ш	NPS	1/2"	WGT.	
SIZE	_ A	В	ы		U	uı	uz	_			F1	H1	(kg)	
11/2"	170	94	70	199	130	25	15,75	90	50,5	34,8	25	9,4	8,6	
2"	170	99	76	205	130	25	15,75	90	64	47,5	25	9,4	8,9	

												ļ.	l
					DIME	NSION	IS (mm) DIN					
SIZE	Α	В	B1	С	D	d1	d2	Е	F	н	DN	DN 15	WGT.
SIZE	A	В	ы		U	uı	uz	_			F1	H1	(kg)
DN 40	170	94	70	199	130	25	15,75	90	50,5	38	34	10	8,6
DN 50	170	99	76	205	130	25	15,75	90	64	50	34	10	8,9


Clamp ferrules DIN 32676 Series A; Tube weld DIN 11866 Series A (DIN 11850 Series 2).

					DIME	NSION	IS (mm) ISO						
SIZE	А	В	B1	С	D	d1	d2	Е	_	н	DN	15	WGT.	
SIZE	A	D .	ы	٥	U	uı	uz		Г		F1	H1	(kg)	
DN 32	170	93	70	199	130	25	15,75	90	64	38,4	25	10,3	8,6	
DN 40	170	99	76	205	130	25	15,75	90	64	44,3	25	10,3	9,2	

Clamp ferrules DIN 32676 Series B; Tube weld DIN 11866 Series B (ISO 1127 Series 1). Remarks: Special versions or non-standard sanitary clamp ferrules are available on request, both for the inlet/outlet, pressure gauge and drain connections.



Valve without bottom connection.




Valve with bottom connection for condensate drainage.








	MATERIA	LS
POS.	DESIGNATION	MATERIAL
1	Valve body	AISI 316L / 1.4404
2	Cover	AISI 316L / 1.4404
2.1	Bottom cover	AISI 316L / 1.4404
2.2	Gasket	PTFE / TFM® Envelope gasket
2.3	Safety clamp	AISI 316 / 1.4401
3	Centering plate	AISI 316L / 1.4404
4	* Valve stem	AISI 316L / 1.4404
5	* Soft plug	EPDM; PTFE **
6	* Valve plug	AISI 316L / 1.4404
7	* Upper diaphragm	EPDM
8	* Lower diaphragm	PTFE (Gylon)
9	Diaphragm plate	AISI 316L / 1.4404
10	* O-ring	EPDM
11	Diaphragm plate	AISI 316L / 1.4404
12	Stem guide	AISI 316 / 1.4401
13	Spring plate	AISI 316 / 1.4401
14	Nut	Stainless steel A2-70
15	Washer	AISI 316 / 1.4401
16	* Adjustment spring	AISI 302 / 1.4300
17	Top spring plate	AISI 316 / 1.4401
18	Retaining washer	Stainless steel A2-70
19	Regulating nut	AISI 316L / 1.4404
20	Adjustment screw	Brass
21	O-ring	NBR
22	Bearing	Corrosion resistant steel
23	Ext. bowed shaft ring	Stainless steel
24	Cover nut	Plastic
25	Bolts	A2-70





FDA / USP Class VI seals certificate on request.


For viton diaphragm the only approval available is the FDA (pos. 7).



Valve without bottom drain, for clean gases.







Valve with condensate drain for clean steam.







ORDERING CODES P173											
Valve model	P17D	4	4	т	М	ı	Х	Х	Х	DI	32
P173 – AISI 316L / 1.4404 Diaphragm pressure reducing valve with drain	P17D										
P173 – AISI 316L / 1.4404 Diaphragm pressure reducing valve without drain	P17										
Outlet spring range											
0,8 to 1,5 bar		4									
1 to 3 bar		5									
1,5 to 5 bar		6									
Flow capacity											
Kvs – 5,5			4								
Kvs – 8,5 (Only available w/ BPE 2" and DIN DN50. Limited to a max. 4 bar inlet press.)			6								
Diaphragm material											
PTFE (Gylon)				Т							
Seat material											
Metal to metal (non-standard)					М						
EPDM					Е	1					
PTFE					Т						
FPM / Viton					٧						
Regulating knob and top cap											
Stainless steel regulating knob						ı	1				
Top cap (adjusting screw sealing)						Т	1				
Stainless steel regulating knob w/ diaphragm cover leakage connection in case of diaphragm	gm failure					L					
Top cap (adjusting screw sealing) w/ diaphragm cover leakage connection in case of diaph	<u> </u>					U					
Gauge port options											
Without gauge ports							Х				
Tri-clamp gauge port on the left side (rel. to the flow direction) – downstream pressure – 1	connecti	on					7				
Tri-clamp gauge port on the right side (rel. to the flow direction) – downstream pressure – 1							6				
Tri-clamp gauge port on the left side (rel. to the flow direction) – upstream and downstream			onn.	a)			9				
Tri-clamp gauge port on the right side (rel. to the flow direct.) – upstream and downstream							8				
Tri-clamp gauge port on both sides – downstream pressure – 2 connections	p			,			5				
Threaded gauge port on the left side (rel. to the flow direction) – downstream pressure – IS	SO 7 Rp	1/4"					4				
Threaded gauge port on the right side (rel. to the flow direction) – downstream pressure –			,,				3				
Threaded gauge port on left side (rel. to the flow direction) – upstream and downstream pro-				SO 7	7 Rp	1/4"	-				
Threaded gauge port on right side (rel. to the flow direction) – upstream/downstream press					_ <u> </u>		0				
Threaded gauge port on both sides – downstream pressure – ISO 7 Rp 1/4"	5410 2				117	., .	2				
Threaded gauge port on the left side (rel. to the flow direction) – downstream pressure – 1/	/4" NPT						w				
Threaded gauge port on the right side (rel. to the flow direction) – downstream pressure –		-					Y				
Threaded gauge port on left side (rel. to the flow direction) – upstream and downstream pro-			1	/4" N	VPT		U				
Threaded gauge port on right side (rel. to the flow direction) – upstream and downstream p						JPT	V				
Threaded gauge port on both sides – downstream pressure – 1/4" NPT	probbaro				7-1		z				
Surface finish b)							_				
Standard surface finish								Х			
Mirror mechanical polished external surfaces (SF1)								P			
Will of The chambal peliened external canades (et 1)								E			
, , ,								_			
Electropolished internal wetted parts (SF5)									Х		
Electropolished internal wetted parts (SF5) Special features									0		
Electropolished internal wetted parts (SF5) Special features None									_		
Electropolished internal wetted parts (SF5) Special features None Degreased for oxygen									C		
Electropolished internal wetted parts (SF5) Special features None Degreased for oxygen CIP / SIP lock system									С		
Electropolished internal wetted parts (SF5) Special features None Degreased for oxygen CIP / SIP lock system Pipe connection									С	D	
Electropolished internal wetted parts (SF5) Special features None Degreased for oxygen CIP / SIP lock system Pipe connection Clamp ferrule ASME BPE									С	D	
Electropolished internal wetted parts (SF5) Special features None Degreased for oxygen CIP / SIP lock system Pipe connection Clamp ferrule ASME BPE Clamp ferrule DIN (DIN 32676-A)									С	F	
Electropolished internal wetted parts (SF5) Special features None Degreased for oxygen CIP / SIP lock system Pipe connection Clamp ferrule ASME BPE Clamp ferrule DIN (DIN 32676-A) Clamp ferrule ISO (DIN 32676-B)									С	F	
Electropolished internal wetted parts (SF5) Special features None Degreased for oxygen CIP / SIP lock system Pipe connection Clamp ferrule ASME BPE Clamp ferrule DIN (DIN 32676-A) Clamp ferrule ISO (DIN 32676-B) ETO according to ASME BPE									С	F E DI	
Electropolished internal wetted parts (SF5) Special features None Degreased for oxygen CIP / SIP lock system Pipe connection Clamp ferrule ASME BPE Clamp ferrule DIN (DIN 32676-A) Clamp ferrule ISO (DIN 32676-B) ETO according to ASME BPE ETO according to DIN 11866-A (DIN 11850-2)									C	F E DI FI	
Electropolished internal wetted parts (SF5) Special features None Degreased for oxygen CIP / SIP lock system Pipe connection Clamp ferrule ASME BPE Clamp ferrule DIN (DIN 32676-A) Clamp ferrule ISO (DIN 32676-B) ETO according to ASME BPE ETO according to DIN 11866-A (DIN 11850-2) ETO according to ISO 1127-1									C	F E DI	
Electropolished internal wetted parts (SF5) Special features None Degreased for oxygen CIP / SIP lock system Pipe connection Clamp ferrule ASME BPE Clamp ferrule DIN (DIN 32676-A) Clamp ferrule ISO (DIN 32676-B) ETO according to ASME BPE ETO according to DIN 11866-A (DIN 11850-2) ETO according to ISO 1127-1 Size									С	F E DI FI	22
Electropolished internal wetted parts (SF5) Special features None Degreased for oxygen CIP / SIP lock system Pipe connection Clamp ferrule ASME BPE Clamp ferrule DIN (DIN 32676-A) Clamp ferrule ISO (DIN 32676-B) ETO according to ASME BPE ETO according to DIN 11866-A (DIN 11850-2) ETO according to ISO 1127-1 Size DN 32 (available with ISO connections only)									С	F E DI FI	32
Electropolished internal wetted parts (SF5) Special features None Degreased for oxygen CIP / SIP lock system Pipe connection Clamp ferrule ASME BPE Clamp ferrule DIN (DIN 32676-A) Clamp ferrule ISO (DIN 32676-B) ETO according to ASME BPE ETO according to DIN 11866-A (DIN 11850-2) ETO according to ISO 1127-1 Size DN 32 (available with ISO connections only) 11/2" or DN 40									С	F E DI FI	40
Electropolished internal wetted parts (SF5) Special features None Degreased for oxygen CIP / SIP lock system Pipe connection Clamp ferrule ASME BPE Clamp ferrule DIN (DIN 32676-A) Clamp ferrule ISO (DIN 32676-B) ETO according to ASME BPE ETO according to DIN 11866-A (DIN 11850-2) ETO according to ISO 1127-1 Size DN 32 (available with ISO connections only)									C	F E DI FI	

a) Under special request and after approval of technical solution; b) Consult IS PV20.00 for further details and other surface finish options.

